

Anlage 1

Rubber Dam Clamp Stainless Steel

Heraeus

Heraeus Kulzer, LLC
300 Heraeus Way
South Bend, IN 46614-2517
1-800-431-1785
www.heraeus-kulzer-us.com

Made in USA

55370104 R 5/12

For use by dental professionals only.

Inspect and sterilize clamp before each use. For optimum use, use a general purpose cleaner prior to sterilization.

Do not heat clamp above 350°F/177°C.

Choose the appropriate size and style clamp giving consideration to the tooth size, location, gingival architecture, and matrix needs. **Practice proper rubber dam technique at all times.** Use rubber dam punch to place holes in the rubber dam according to applicable dentition. **Attach floss to both of the clamp jaw forcep holes.** Mount the rubber dam to the rubber dam frame, and tie floss safety lines to the frame. Set the clamp into prepared rubber dam and place on tooth, checking the stability of the clamp before proceeding. Use additional floss to seat rubber dam between isolated teeth.

Caution: Modification, over-extending, bending, or use exceeding one year may cause breakage. Do not place clamp in mouth until the rubber dam has been properly placed. Clamp could become a choking or safety hazard if dropped or broken in the mouth without proper use of the rubber dam at all times.

For Technical Assistance, call 1-800-431-1785.

Nur zur zahnärztlichen Verwendung.

Vor jedem Gebrauch die Klammer kontrollieren und sterilisieren. Am besten vor dem Gebrauch ein Allzweckreinigungsmittel verwenden.

Die Klammer nicht auf mehr als 177°C erhitzen.

Wählen Sie die geeignete Größe und Form der Klammer unter Berücksichtigung der Zahngröße und -lage, des Zahnfleischzustands und der notwendigen Abstände. **Führen Sie stets die korrekte Kofferdam Technik aus.** Benutzen Sie eine Kofferdam-Lochzange, um die Löcher im Kofferdam gemäß der vorhandenen Zahnstellung zu platzieren. **Bringen Sie einen Zahnseiden-Absicherungsfaden in den beiden Löchern der Klammerzange an.** Setzen Sie den Kofferdam auf den Kofferdam-Rahmen auf und befestigen Sie den Absicherungsfaden am Rahmen. Setzen Sie die Klammer auf den vorbereiteten Kofferdam und platzieren Sie ihn auf dem Zahn. Prüfen Sie die Festigkeit der Klammer vor der weiteren Behandlung. Benutzen Sie weitere Zahnseide, um den Kofferdam zwischen isolierten Zähnen zu sichern.